

## Nelson-Rigg Route 1 Road Trip Saddlebag Fitment

Fitments Confirmed Through 2024 Models. Please visit our website for updates.

**All hardware (bolts, washers and spacers) are provided for installation on below vehicles.**

Motorcycle Brand	Years	Hardware Included	Spacers to be used	Bolts to be used
<b>BMW</b>				
R18	2020 - 2024	Yes	Qty 4: M8 x 6mm Spacers	Qty 4: x 8M - 1.25 x 25mm
<b>Honda</b>				
Rebel 500	2017 to Current	Yes	Qty 4: M8 x 6mm Spacers	Qty 4: M8 - 1.25 x 25mm
Rebel 300	2017 to Current	Yes	Qty 4: M8 x 6mm Spacers	Qty 4: M8 - 1.25 x 25mm
<b>Harley Davidson</b>				
Blackline - FXS *	2010-2012	Yes	Vehicles use factory bolts only	
Night Train - FXSTB	2000-2009	Yes		
Springer - FXSTS	2000-2007	Yes		
Cross Bones - FLSTSB	2008-2011	Yes		
Fat Boy - FLSTF	2000-2017	Yes		
Fat Boy - FLFB	2018 to Current	Yes		
Deluxe - FLSTN	2005-2017	Yes		
Deluxe - FLDE	2018 to Current	Yes		
Standard - FXST	2000-15 & 2020 - 2023	Yes		
Standard Custom - FXSTC	2007-11 & 2014	Yes		
Street Bob - FXBB	2018 to Current	Yes		
Low Rider- FXDL *	2000-17	Yes		
Wide Glide - FXDWG *	2000-17	Yes		
Street Bob - FXDB *	2006-17	Yes		
Super Glide - FX *	2000-2012	Yes		
Super Glide Custom - FXD *	2005-2015	Yes		
Breakout - FXSB	2013-2017	Yes		
Breakout - FXBR	2023 to Current	Yes		
Softail Slim - FLS	2012-17	Yes	Vehicles use factory bolts with included M10 or 1.5mm washer	
Softail Slim - FLSL	2018 - 2021	Yes		
Low Rider - FXLR	2018 to Current	Yes	Replace OEM fender bolts with 1/4" spacers and 3/8" x 1.5" bolts	
Low Rider - FXLRS	2022 to Current	Yes		
<b>Indian</b>				
Scout & Scout Sixty**	2015 to 2023	Yes	Qty 4: M8 x 6mm Spacers	Qty 4: M8 - 1.25 x 25mm
<b>Kawasaki</b>				
Vulcan 900 Classic	2009 to Current	Yes	All vehicles use factory bolts	
Vulcan 900 Custom	2010 to Current	Yes		
Kawasaki Vulcan S	2015 to Current	Yes		
Eliminator	2023 to Current	Yes	Qty 4: M8 x 12mm Spacers	Qty4: 8M - 1.25 x 60mm
<b>Suzuki</b>				
C50	2005 to Current	Yes	Qty 4: M8 x 6mm Spacers	Qty4: 8M - 1.25 x 60mm
M109R	2006 to Current	Yes	Qty 4: M8 x 6mm Spacers	Qty2: 8M - 1.25 x 80mm Qty2: 8M - 1.25 x 60mm
Boulevard M50	2010 to Current	Yes	Qty 4: M8 x 6mm Spacers	Qty2: 8M - 1.25 x 80mm Qty2: 8M - 1.25 x 60mm

\*Relocate Turn Signals

\*\* (not Bobber or Rogue)

Below vehicles require some additional hardware to mount.  
Most can be found at local hardware stores or on-line.

Motorcycle Brand	Years	Hardware Included	Spacers M10 and 1/4" not included	Bolts needed to be purchased separately
<b>Honda</b>				
Shadow Aero	2006 to 2023	No	Not Needed	QTY 4: M10 - 1.25 x 45mm
Shadow Phantom	2024 to Current	No	Qty 4: M8 x 12mm Spacers	Qty 2: M10 - 1.25 x 50mm QTY 2: M10 - 1.25 x 40mm QTY 4: M10 Washers
VTX 1300	2003 to 2009	No	Qty 2: M8 x 12mm Spacers Qty 2: M10 x 12mm Spacers	Qty 2: M8 - 1.25 x 35mm Qty 2: M10 - 1.25 x 40mm QTY 2: M10 Washers
VLX 600 Shadow	1993 to 2007	No	Qty 2: M8 x 12mm Spacers Qty 2: M8 x 6mm Spacers	Qty 4: M8 - 1.25 x 70mm
<b>Harley Davidson</b>				
Fat Bob - FXDF	2008-17	No	Qty 4: 1/4" Spacers	Qty 4: 3/8"-16 x 1.25"
<b>Suzuki</b>				
Volusia 800	2001 to 2007	No	Qty 4: M8 x 12mm Spacers	Qty 2: M8 - 1.25 x 70mm
<b>Triumph</b>				
Speedmaster	2004 - 2016	No	Qty 4: M8 x 12mm Spacers	Qty 2: M8 - 1.25 x 45mm
<b>Yamaha</b>				
Stryker	2010 to 2016	No	Qty 4: M8 x 12mm Spacers	Qty 2: M8 - 1.25 x 50mm Qty 2: M8 - 1.25 x 45mm
Roadstar Warrior	2002 to 2010	No	Qty 4: M8 x 12mm Spacers	Qty 4: M8 - 1.25 x 40mm
V-star 1100 Classic	1998 to 2008	No	Qty 4: M8 x 12mm Spacers	Qty 4: M8 - 1.25 x 35mm
V-Star 650 Classic	1998 to 2008	No	Qty 4: M8 x 6mm Spacers	Qty 4: M8 - 1.25 x 40mm
Bolt***	2013 to 2023	No	Qty 4: M8 x 12mm Spacers Qty 2: M8 x 6mm Spacers	Qty 4: M8 - 1.25 x 70mm

\*\*\*w/o Piggyback Shock Reservoir