## **Instructions** ANT-GROM

Please read instructions carefully before installation. We recommend this product be installed by a qualified, and experienced motorcycle technician. If you are unsure of any of the below directions and or your ability to correctly and securely install this product, please contact us or your local dealer for help. Below diagrams show typical installation, your motorcycle may be different so please use diagrams as a guide.

Make sure your motorcycle is clean and free from dirt, road grime etc. where the Nelson-Rigg® luggage mounts.

## Antenna Grommet Installation

If your motorcycle is equipped with a removable antenna we suggest you remove it before covering your vehicle.

If your antenna is not removable, use the supplied antenna grommet.

## Installation:

Step 1: Determine the correct location on the cover where the antenna will come through the material. Install the cover on the vehicle but leave the section where the antenna is located uncovered. Pull the fabric towards the antenna to reveal where the hole needs to be made. Mark with a pen or pencil and remove the cover.

Step 2: Using a screwdriver or sharp object, pierce the cover where marked. The hole needs to be at least the diameter of the antenna. Please note, if using with our dust covers, it will be necessary to remove the material for the grommet to pass through. Use the grommet as a template and mark on the fabric a 1" diameter circle centering the mark made in step 1. Carefully cut out this section before installing the grommet.

Step 3: Once you have determined the correct position for the grommet, simply place the larger of the two pieces on the outside of the cover then position the smaller piece directly underneath and snap the two together. It might be necessary to use a rubber mallet or vice. Once they are successfully joined, re-fit the cover making sure the hole lines up correctly and does not pull the fabric or put tension on the antenna.

You can view an installation video tutorial on our You Tube page at www.youtube.com/nelsonriggusa

Warning

Read the installation instructions and make yourself familiar with the process of installing the Nelson-Rigg\* products) on your bike. It is your responsibility to mount the product correctly and securely as outlined in these instructions. Nelson-Rigg\* products are intended for use at USA street legal speeds as poster by the individual States. Nelson-Rigg\* loggage must not be overloaded. Max carrying capacity is 10 lbs per bag or the maximum load suggested by the machine to adhere to these warrings may result in but not be limited to: the lungage becoming detached, the product becoming tangled in moving natic of the

nanufacturer of the vehicle, whichever is less.

alliare to adhere to these warnings may result in, but not be limited to: the luggage becoming detached, the product becoming tangled in moving parts of the ehicle, unstable vehicle dynamics, reduction in the ability to control the vehicle. The result(s) of could lead to serious injury.

Allower life, a plant and advanced in the plant plant part of the vehicle of the plant part of the plant part of the plant plant part of the p



